

**No Tension Feeder HF-52, HF-53**

This option when used with the tape cutter means problem free cutting of stretching tapes. The HF-52 type gets its power supply through the tape cutting machine, and is equipped with a tape end detecting function. The HF-52 can be attached to H-510.

**No Tension Feeder HF-52, HF-53**

No Tension Feeder

**Model**

HF-52,53